


MX20

LED Display Controller



Specifications

| Document Version | Release Date | Description |
|------------------|--------------|--|
| V1.4.1 | 2024-08-13 | Added certification information for UL and CB. |
| V1.4.0 | 2024-06-13 | • The "Layer Setting" in the LCD interface of the device has been renamed to "Layer Parameters". Now, it only shows the parameters without allowing any modifications. |
| | | Added information for supported receiving card models. |
| V1.0.1 | 2023-07-04 | Updated the supported driver ICs for frame rate adaptive. |
| V1.0.0 | 2023-06-09 | First release |

Change History

Introduction

The MX20 is an all-in-one LED display controller in the brand-new control system COEX series of Xi'an NovaStar Tech Co., Ltd. (hereinafter referred to as NovaStar). This controller integrates video processing and video control into one box and offers 2x HDMI 1.3, 1x 3G-SDI input connectors, 6x Ethernet output ports, and 2x 10G optical ports. It can also work with the brand-new software VMP (Vision Management Platform) to provide a better operation and control experience.

Certifications

CE/FCC/IC/UL/CB

If the product does not have the relevant certifications required by the countries or regions where it is to be sold, please contact NovaStar to confirm or address the problem. Otherwise, the customer shall be responsible for the legal risks caused or NovaStar has the right to claim compensation.

Features

Inputs and Outputs

- 2 types of inputs
 - 2x HDMI 1.3 (with loop through)
 - 1x 3G-SDI (with loop through)
- 10-bit and 8-bit video inputs
- 3 types of outputs
 - 6x Gigabit Ethernet ports, load capacity up to 3.9 million pixels

Advanced Features

- 3 independent layers
 Support up to 3 layers and layer priority adjustment in Z order.
- Image scaling Support 4 image scaling modes: custom, pixel to pixel, snap to canvas and fill screen.
- 14Ch Color Correction Support precise adjustment to hue, saturation and brightness of black, white and the 12 derived standard colors of the red, green and blue primary colors.

- 2x 10G optical ports
- 1x SPDIF digital audio port
- 3 types of controls
 - 1x Genlock signal input (with loop through)
 - 2x Ethernet control ports
 - 1x Auxiliary port
- Full-Grayscale Calibration
 Work with NovaStar's high-precision calibration
 system and the C3200 scientific grade camera to
 generate unique calibration coefficients for each
 grayscale, ensuring uniformity of each grayscale
 and dramatically improving the image quality.
- Latency
 - Support low latency and the controller load capacity is not reduced. The latency at the controller is 0 frame (less than 1 ms) in Send-Only Controller working mode and 1 frame in All-In-One Controller working mode.



- Support additional latency. Zero to two frames of latency can be added at the controller.
- Preset

For optimal display in various scenarios, users can adjust display parameters such as layers, brightness, color temperature, and gamma ahead of time and save them as presets. Users can save up to 128 customizable presets which can be easily applied or switched with just one click.

No rectangle restriction
 No rectangle restriction for irregular screens. This
 means when calculating resolutions, blank pixels do
 not count towards the total capacity. The used load
 capacity of Ethernet ports is the sum of the
 resolutions of all cabinets.

Frame Rate Adaptive

Automatically adapt to video inputs with different frame rates ranging from 23.98 Hz to 144 Hz, and support the automatic calculation of optimal screen parameters based on the input source's frame rate. This ensures that the brightness deviation of the screen remains within 5% across different frame rates. It also supports precise frame rate adjustment in 0.01 Hz increments.

- Two working modes Support the All-In-One Controller and Send-Only Controller working modes.
 - In the Send-Only Controller mode, the latency can be reduced by one frame.
 - In the All-In-One Controller mode, the layer and scaling functions are available.
- Display system monitoring Support monitoring of the device status and screen status. Any fault and alarm information can be reported actively.

Device Controls

- VMP software control The device can be connected to the VMP software to provide easy and convenient operations and smart device management.
- SNMP and Art-Net protocols supported

Table 1-1 Function Limitations

 Cascading control via Ethernet The Gigabit Ethernet control ports support TCP/IP protocol and star topology. No switch or router is needed to deploy multiple devices on the same LAN via device cascading as the network switching function is already built in.

| Function | Limitation | |
|----------------------------|--|--|
| Frame Rate Adaptive | To use this function, it is required to pair with the A10s Pro receiving card and specific driver ICs (for detailed IC models, please see the product specifications on the NovaStar website at https://www.novastar.tech/). Additionally, you must use the Cabinet Tool provided by NovaStar to adjust the driver IC parameters for different frame rates, which will generate the required NCP file. | |
| Full Grayscale Calibration | It is required to work with the A10s Pro receiving card and users need to use a C3200 camera to perform full-grayscale calibration. | |
| Low Latency | Low Latency cannot be enabled simultaneously with Genlock. Moreover, it is recommended to ensure all Ethernet ports load the cabinets vertically and share the same Y coordinate (all set to 0) when Low Latency is enabled. | |

Table 1-2 Supported Receiving Card Models

| Receiving Card Model | Supported |
|-------------------------|-----------|
| A5s Plus | Yes |
| A7s Plus | Yes |
| A8s and its series | Yes |
| A8s-N | Yes |
| A8s Pro and its series | Yes |
| A10s Pro and its series | Yes |

Appearance

Front Panel



| Name | Description |
|-------------------|---|
| Running Indicator | Solid red: Standby Solid blue: The device is being started. Solid green: The device is running normally. Flashing red: The device is running abnormally. |
| Standby Button | Press the button to power on or power off the device.Hold down the button for 5s or longer to restart the device. |
| USB 2.0 | Connect to a USB drive only to export the device diagnostic result. Only the NTFS and FAT32 file systems are supported. Others are not supported. |
| LCD Screen | A 2-inch screen that displays the device status, menus, submenus and messages for parameter settings |
| Knob | On the home screen, press the knob to enter the main menu screen. On the main menu screen, rotate the knob to select a menu item or adjust the parameter value. Press the knob to confirm the operation. Hold down the knob and BACK button simultaneously for 5s or longer to lock or unlock the buttons. |
| ВАСК | Go back to the previous menu or cancel the current operation. |

Rear Panel





| Inputs | | | |
|-------------|-----|--|---|
| Туре | Qty | Description | |
| HDMI 1.3 IN | 2 | Resolution Max resolution: 1920×1200@60Hz Min resolution: 800×600@60Hz | |
| | | Max width/height | Max width: 3840 pixels (3840×600@50Hz) Max height: 2560 pixels (800×2560@50Hz) |

| r | | 1 | | | |
|---------------|-----|--|---|--|--|
| | | Frame Rate 23.98 / 24 / 25 / 29.97 / 30 / 47.95 / 48 / 50 / 59.94 / 60 / 72 / 75 85 / 100 / 119.88 / 120 / 143.86 / 144 Hz | | | |
| | | EDID Support standard resolutions, up to 1920×1080@60Hz. | | | |
| | | management | Support custom input resolutions. | | |
| | | HDCP HDCP 1.4 compliant, backwards compatible with HDCP 1.3. | | | |
| | | Interlaced signal inputs | Not supported | | |
| 3G-SDI IN | 1 | Standards Support ST-424 (3G), ST-292 (HD) and ST-259 (SD) standard video inputs. | | | |
| | | | Support 3G-Level A/Level B (DS mode). | | |
| | | Resolution | Max resolution: 1920×1080@60Hz | | |
| | | Frame Rates | 23.98/24/25/29.97/30/47.95/48/50/59.94/60 Hz | | |
| | | Interlaced signal inputs | Support MQ level deinterlacing. The interlaced signals will be automatically detected and converted to progressive signals. | | |
| Outputs | | | | | |
| Туре | Qty | Description | | | |
| 1–6 | 6 | Gigabit Ethernet output ports. Support hot backup between Ethernet ports. | | | |
| | | Max device load capacity: 3.9 million pixels | | | |
| | | The maximum load capacity per Ethernet port is as follows. For details, see the Ethernet Port Load Capacity section. | | | |
| | | - 8bit@60I | - 8bit@60Hz: 659,722 pixels | | |
| | | | 10bit@60Hz: 329,861 pixels. When the controller works with the A10s Pro receiving card, the capacity can be up to 494,791 pixels. | | |
| OPT 1–2 | 2 | 10G optical outp | 10G optical output ports | | |
| | | OPT 1 transm | its the data of Ethernet ports 1 to 6. | | |
| | | OPT 2 is the copy channel of OPT 1. | | | |
| HDMI 1.3 LOOP | 2 | HDMI loop through. Up to 8 devices can be cabled in one loop. | | | |
| 3G-SDI LOOP | 1 | SDI loop through. Up to 8 devices can be cabled in one loop. | | | |
| SPDIF OUT | 1 | A digital audio output (Reserved) | | | |
| Controls | | | | | |
| Туре | Qty | Description | | | |
| ETHERNET | 2 | Gigabit Ethernet control ports. Support TCP/IP protocol and star topology. | | | |
| | | They have the same functions without priority and order, and can be connected to VMP software. No switch or router is needed to deploy multiple devices on the same LAN via device cascading as the network switching function is already built in. Up to 20 MX20 devices can be cascaded. | | | |
| GENLOCK | 1 | A pair of Genloc | k signal connectors. Support Bi-Level, Tri-Level, and Blackburst. | | |
| | | • IN: Accept the | sync signal. | | |
| | | • LOOP: Loop t | he sync signal. | | |
| | | | out signal supports a frame rate range from 23.98 Hz to 60 Hz. For k signal generators, up to 20 MX20 devices can be cascaded. | | |
| | | | | | |

| AUX | 1 | An auxiliary port that connects to the central control device (RS232) (Reserved) | |
|--------------------------------|---|--|--|
| Power | | | |
| 100-240V~, 50/60Hz, 2- 0.8A | 1 | An AC power input connector and switch. | |

Dimensions





Tolerance: ±0.3 [±0.012] Unit: mm [inch]

Product Specifications

| Electrical Specifications | Power input | 100-240V~, 50/60Hz, 2- 0.8A |
|------------------------------|---------------------------|---------------------------------|
| Specifications | Maximum power consumption | 50 W |
| Operating Environment | Temperature | -20°C to +50°C |
| Livionnent | Humidity | 0% RH to 80% RH, non-condensing |



| Storage Environment | Temperature | -30°C to +80°C | |
|----------------------------|---|---|--|
| Environment | Humidity | 0% RH to 95% RH, non-condensing | |
| Physical Specifications | Dimensions | 482.6 mm × 49.9 mm × 384.0 mm | |
| opecifications | Net weight | 4.5 kg | |
| | Gross weight | 8.1 kg | |
| | | Note: It is the total weight of the product, accessories, and packing materials packed according to the packing specifications. | |
| Packing Information | Packing box | 612.0 mm × 220.0 mm × 600.0 mm, kraft paper box | |
| mormation | Accessory box | 408.0 mm × 294.0 mm × 51.0 mm, white cardboard box | |
| | Accessories | • 1x Power cord | |
| | | • 1x Ethernet cable | |
| | | • 1x HDMI cable | |
| | | 1x Certificate of Approval | |
| IP Rating | IP20 | | |
| | Please prevent the product from water intrusion and do not wet or wash the product. | | |

The amount of power consumption may vary depending on various factors such as product settings, usage, and environment.

Video Source Specifications

| Input | Resolut | tion | Color Space | Sampling | Bit Depth | Integer Frame Rate (Hz) |
|----------|---------|-----------|-------------|----------|-----------|-------------------------|
| HDMI 1.3 | 2K1K | 2560×1440 | RGB / YCbCr | 4:4:4 | 10bit | |
| | | (Forced) | | | 8bit | 24/25/30 |
| | | | YCbCr | 4:2:2 | 8/10bit | |
| | | 1920×1080 | RGB / YCbCr | 4:4:4 | 10bit | 24/25/30/48/50 |
| | | | | | 8bit | 24/25/30/48/50/60 |
| | | | YCbCr | 4:2:2 | 8/10bit | 24/23/30/46/30/60 |
| 3G-SDI | 2K1K | 2048×1080 | YCbCr | 4:2:2 | 10bit | 24/25/30/48/50/60 |
| | | 1920×1080 | | | | |

Note:

The table above only displays a selection of common resolutions and integer frame rates. Decimal frame rates are also supported, allowing for automatic frame rate adaptation from the highest frame rate of each resolution down to 23.98/29.97/47.95/59.94/71.93/119.88/143.86 Hz

Ethernet Port Load Capacity

When Working with A10s Pro Receiving Card

The formula of calculating the load capacity per Ethernet port and the detailed parameters are as follows.

• 8bit: Load capacity × 24 × Frame rate < 1000 × 1000 × 0.95



| 10bit: Load capacity × 32 × Frame rate < 1000 × 1000 × 1000 × 0.95 | | | | | |
|--|--|-----------|--|--|--|
| Max Load Capacity | Max Load Capacity per Ethernet Port (Pixels) | | | | |
| Frame Rate / Bit Depth | 8bit | 10bit | | | |
| 24 Hz | 1,649,305.556 | 1,236,979 | | | |
| 25 Hz | 1,583,333 | 1,187,500 | | | |
| 30 Hz | 1,319,444 | 989,583 | | | |
| 50 Hz | 791,667 | 593,750 | | | |
| 60 Hz | 659,722 | 494,792 | | | |
| 120 Hz | 329,861 | 247,396 | | | |
| 144 Hz | 274,884 | 206,163 | | | |

When Working with Other Armor Series Receiving Cards

The formula of calculating the load capacity per Ethernet port and the detailed parameters are as follows.

• 8bit: Load capacity × 24 × Frame rate < 1000 × 1000 × 1000 × 0.95

| Max Load Capacity per Ethernet Port (Pixels) | | | |
|--|---------------|---------|--|
| Frame Rate / Bit Depth | 8bit | 10bit | |
| 24 Hz | 1,649,305.556 | 824,653 | |
| 25 Hz | 1,583,333 | 791,667 | |
| 30 Hz | 1,319,444 | 659,722 | |
| 50 Hz | 791,667 | 395,833 | |
| 60 Hz | 659,722 | 329,861 | |
| 120 Hz | 329,861 | 164,931 | |
| 144 Hz | 274,884 | 137,442 | |

• 10bit: Load capacity × 48 ×Frame rate < 1000 × 1000 × 1000 × 0.95


Notes and Cautions

Notes for Battery

- The battery is not intended to be replaced.
- Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery can result in an explosion.
- Leaving a battery in an extremely high temperature surrounding environment can result in an explosion or the leakage of flammable liquid or gas.
- A battery subjected to extremely low air pressure may result in an explosion or the leakage of flammable liquid or gas.

Notes for Installation

When the product needs to be installed on the rack, 4 screws at least M5*12 should be used to fix it. The rack for installation shall bear at least 18 kg weight.



- Elevated Operating Ambient If installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack environment may be greater than room ambient. Therefore, consideration should be given to installing the equipment in an environment compatible with the maximum ambient temperature (Tma) specified by the manufacturer.
- Reduced Air Flow Installation of the equipment in a rack should be such that the amount of air flow required for safe operation of the equipment is not compromised.
- Mechanical Loading Mounting of the equipment in the rack should be such that a hazardous condition is not achieved due to uneven mechanical loading.
- Circuit Overloading Consideration should be given to the connection of the equipment to the supply circuit and the effect that overloading of the circuits might have on overcurrent protection and supply wiring. Appropriate consideration of equipment nameplate ratings should be used when addressing this concern.
- Reliable Earthing Reliable earthing of rack-mounted equipment should be maintained. Particular attention should be given to supply connections other than direct connections to the branch circuit (e.g. use of power strips).

Others

This product can only be placed horizontally. Do not mount vertically or upside-down.

This is Class A product. In a domestic environment, this product may cause radio interference in which case the user may be required to take adequate measures.

Copyright © 2024 Xi'an NovaStar Tech Co., Ltd. All Rights Reserved.

No part of this document may be copied, reproduced, extracted or transmitted in any form or by any means without the prior written consent of Xi'an NovaStar Tech Co., Ltd.

Trademark

NOVASTAR is a trademark of Xi'an NovaStar Tech Co., Ltd.

Statement

Thank you for choosing NovaStar's product. This document is intended to help you understand and use the product. For accuracy and reliability, NovaStar may make improvements and/or changes to this document at any time and without notice. If you experience any problems in use or have any suggestions, please contact us via the contact information given in this document. We will do our best to solve any issues, as well as evaluate and implement any suggestions.

Official website www.novastar.tech

Technical support support@novastar.tech